

Laser Fluorescence Analysis of Phytoplankton: Beyond Chlorophyll Concentration


A.M. Chekalyuk^{1,3}, F.E. Hoge³,
R.N. Swift², J.K. Yungel², P.E. Lyon²


¹*Hampton University*, ²*EG&G Services*,

³*NASA Goddard Space Flight Center*

Wallops Flight Facility, *chekaluk@osb.wff.nasa.gov*


Objective: Remote Assessment of Phytoplankton Physiology, Pigments and Functional Groups





Active Fluorescence: A powerful Analytical Tool


Optical Complexity of Coastal Waters: CDOM, complex algal composition, suspended sediments, high turbidity



Active Fluorescence:

- **High sensitivity & Spectral discrimination** between CDOM and pigment fluorescence, Raman and elastic scattering
- **Enhanced selectivity** provided by spectral fluorescence excitation
- Potential for **assessment of algal pigments, physiology, and dominant groups**
- **Variety of platforms:** ships, drifters, buoys, autonomous vehicles, airplanes (LIDAR), satellites (PhyLM?)
- **New: Works remotely** and can be **as accurate as HPLC**









October 2003: Airborne/Shipboard Laser Measurements in the Chesapeake and Delaware Bays




**Airborne
Oceanographic
LIDAR:** Chl-a,
Phycoerythrin, and
CDOM fluorescence;
Variable fluorescence
(physiology)




**Shipboard Laser
Fluorometer:** Chl-a,
Phycoerythrin, and
CDOM fluorescence




**Laser Phytoplankton
Analyzer:** FEX_5 (473,
532, 639, 651, 666 nm),
Hyperspectral FEM,
Variable fluorescence
(physiology)




**Laser Excitation/Emission
Matrix (LEEM) Analyzer:**
Hyperspectral FEX/FEM
pigment/CDOM




1. Laser Fluorescence EMission (FEM) Assessment of Chlorophyll-a Concentration







LPA Field Test: Laser FEM Assessment of Chl-a Concentration Can be as Precise, as HPLC Analysis!



Laser
fluorescence/Raman:
single calibration
provides accurate
Chl-a assessment




“Conventional”
fluorometry:
needs frequent
calibrations




Airborne LIDAR + Shipboard HPLC: Validation of Chl-a Ocean Color Algorithms in Coastal and Estuarine Areas


Satellite-Airborne-Shipboard Experiment, October 2003



MODIS Aqua Validation with Airborne AOL and Shipboard HPLC Measurements



- **Shipboard HPLC:** Conversion LIDAR Chl fluorescence into Chl concentration, $\mu\text{g/l}$
- **Airborne LIDAR:** filling space/time satellite-ship gap
- **Satellite Chl algorithm validation in the Chesapeake and Delaware Bays:** “Chl-a2” worked best of all





- Pump&Probe (P&P) LIDAR:
Airborne Fluorescence Assessment of
Phytoplankton Physiology




probe beam


150 m

pump beam






P&P LIDAR: An Upgrade of the Airborne Oceanographic LIDAR (AOL)



P&P LIDAR: 2D Mapping





SeaWiFS Chl-a, March 23, 2002





3. Laser Fluorescence EXcitation (FEX) / EMission (FEM) Analysis: Improved Phytoplankton Pigment/Group Characterization






LPA: Spectral diversity of emission bands allows improved algal/pigment characterization

Cyanobacteria

Rhodophytes

Cryptophytes




Fluorescence EMission (FEM) spectra of phycobilin-containing phytoplankton and cyanobacteria. Chl-a FEM signatures of chlorophyte *Dunaliella tertiolecta* and diatom *Phaeodactylum tricornutum* are displayed for comparison





Table 1. Strains of phytoplankton studied with the LPA system

<i>Dunaliella tertiolecta</i>	Chlorophyte
<i>Nanochloris atomus</i>	Chlorophyte
<i>Storeatula major</i>	Cryptophyte
<i>Synechococcus bacillarius</i>	Cyanobacteria
<i>Synechococcus</i> sp.	Cyanobacteria
<i>Phaeodactylum tricornutum</i>	Diatom
<i>Skeletonema costatum</i>	Diatom
<i>Thalassiosira weissflogii</i>	Diatom
<i>Navicula</i> sp.	Diatom
<i>Aureococcus anophagefferens</i>	Pelagophyte
<i>Pycnococcus provalosii</i>	Prasinophyte
<i>Pavlova lutheri</i>	Prymnesiophyte
<i>Prorocentrum minimum</i>	Dinoflagellate
<i>Porphyridium cruentum</i>	Rhodophyte






FEX Spectra of NPB Algal Species: Assessment of Pigment-Specific FEX Components





Pigment-specific FEX components, $\text{FEX}_{\text{Chl-a}}$, $\text{FEX}_{\text{Chl-b}}$,

$\text{FEX}_{\text{Chl-c}}$ and FEX_{PSC} :

- Deconvolution of FEX species spectra into 10 gaussian components (best fitting)
- Reconstruction of pigment-specific FEX components for each species
- Averaging of the pigment-specific FEX components over a group of species examined




LPA Field Test: Laser Fluorescence Assessment of None-Fluorescent Accessory Pigments






Laser Pigment Analyzer: Identification of Major Algal Groups with 5-wavelength FEX of Chl-a


Dunaliella tertiolecta
Chlorophyte




Nanochloris atomus
Chlorophyte





Aureococcus anophagefferens
Pelagophyte




Synechococcus bacillarius
Cyanobacteria




Synechococcus sp.
Cyanobacteria




Pycnococcus provalosii
Prasinophyte




Thalassiosira weissflogii
Diatom



Prorocentrum minimum
Dinoflagellate






Storeatula major
Cryptophyte



Porphyridium cruentum
Rhodophyte

FEX_5 signatures of phytoplankton and cyanobacteria measured with Laser Phytoplankton Analyzer (LPA). Bar patterns represent efficiency of Chl-a fluorescence excitation with laser excitation at: 1 – 473 nm; 2 – 532 nm; 3 – 639 nm; 4 – 651 nm; 5 – 666 nm

LPA Field Test: Variability in Taxonomic Composition





Advanced Fluorescence Characterization of Algal Species: Laser Excitation/Emission Matrix (LEEM) Analysis

Optical Parametric Oscillator: Wavelength-tunable excitation (410-670 nm)




LEEM pattern: 2D excitation-emission matrix analysis



CCD Spectrograph: Hyperspectral Emission Analysis



Andor




LEEM Analyzer:

- Fast excitation scans (410-670 nm)
- 'Instant' high-resolution FEM analysis
- High sensitivity to analyze natural phytoplankton populations
- Laboratory and shipboard operation

October 2003: Initial Shipboard LEEM Tests




A shipboard prototype system includes an **optical parametric oscillator** (OPO) for wavelength-tunable **excitation** in **410-680 nm** range, and a **CCD spectrometer** for hyperspectral analysis of laser-stimulated pigment emission. The LEEM fluorometer was **tested in the Chesapeake and Delaware Bays** and Delaware River in October 2003.






4. Prototype FEX/FEM LIDAR: Initial Airborne Tests







Prototype FEX/FEM LIDAR: Wavelength-Tunable Excitation & Hyperspectral Signal Detection




Prototype FEX/FEM LIDAR: Airborne Tests in the Chesapeake Bay and Middle Atlantic Bight, Oct. 2003










OPO/ICCD LIDAR measurement protocol:

- OPO excitation: 435 (2 passes), 450, 460, 478, 495, 540 nm, 20 Hz rep.rate, 1 mJ per pulse
- AOL laser: 5 Hz rep. rate, 100 mJ per pulse
- ICCD camera: gated with 100 ns pulse, hyperspectral signal detection in 400-900 nm range

Prototype FEX/FEM LIDAR: Potential for remote identification of dominant algal groups



Laboratory FEX measurements:




- **Blue FEX (435-478 nm): Dinoflagellate dominance (high Chl-c)**
- **Green FEX (495, 540 nm): Presence of phycoerythrin- (PE) containing species with high PEB/PUB ratio**
- **Orange FEM peak (590 nm): Cryptophyte dominance among PE-containing groups (incl. cyanobacteria and rhodophytes)**






PhyLM

5. The Physiology Lidar-Multispectral Mission: Feasibility of Active Fluorescence Measurements




Lidar Objectives

- 辣椒 1 Objective 1: Atmospheric corrections to enhance accuracy and precision of passive data
- 辣椒 2 Objective 2: Active measurements of backscattering, again supporting passive data
- 辣椒 3 **Objective 3: Active, dark-side fluorescence to improve coastal & high-productivity data products**
- 辣椒 4 Objective 4: Active measurements of beam attenuation, for improved phytoplankton carbon products




The PhyLM Mission

PhyLM vs. AOL: Lidar Fluorescence Measurements



AOL single-shot spectra
of Phycoerythrin (590 nm)
and Chlorophyll-a
(685 nm) fluorescence;
OPO excitation: 495 nm



	PhyLM	AOL	PhyLM/AOL
Laser:	1 J	1 mJ (OPO)	10^3
Telescope	5-50 m ²	0.05 m ²	$10^2\text{-}10^3$
Altitude	500 km	0.150 km	$3.3\cdot10^3$
(Altitude) ⁻²	$\sim (1/500)^2$	$\sim (1/0.15)^2$	10^{-7}

PhyLM
Fluorescence
Signal:
Photons...





6. Assessment of Phytoplankton Physiology and Productivity from Natural Fluorescence : Bad News, Good News...





MODIS Natural Fluorescence : Good News (feasible in high latitudes), Bad News (no global assessments of phytoplankton physiology)

$$FLH / ARP = \text{'CFE'} = K_f / (K_{\Sigma} + C_A(\text{PAR}) \cdot f \cdot K_p + K_{NPQ}(\text{PAR}))$$


High PAR:

CFE is controlled by **NPQ**;
Physiology is non-retrievable
(don't shoot the messenger)


Low PAR:

'CFE' depends on
physiology, **f**, and **PAR**

Instantaneous Photosynthetically Available Radiation (IPAR)



Instantaneous (at time of observation) Photosynthetically Available Radiation, 400-700 nm, derived by inverting nLw's. Used in generating ARP for fluorescence.



Fluorescence Assessment of Primary Productivity (PP): Accounting for Variability in Photosynthetic Quantum Yield


Fluorescence assessment of PP: $PP = ARP/Z_{685} \cdot \Phi_P'(\text{PAR}, f) \cdot \phi_e \cdot M_c$

PSII photochemical efficiency under ambient light:



$$\Phi_P'(\text{PAR}, f) = F_v'/F_m' =$$

$$C_A(\text{PAR}) \cdot f \cdot K_p / (K_\Sigma + C_A(\text{PAR}) \cdot f \cdot K_p + K_{NP}(\text{PAR}))$$

Φ_P' :



CFE:



High PAR: $\Phi_P'(\text{PAR}, f)$ drops, but still **depends on physiology**, which is **non-assessable** because the **CFE dependence on physiology is weak**; still **may work regionally** with airborne LIDAR input on ' f '

Low PAR (high latitudes): **should work!**





View from Moon: Global Assessment of Algal Physiology & Productivity from Natural Fluorescence


Moon-based Earth-observing system:

- Continuous dynamic spectral imaging of natural fluorescence under low-light regime can provide global assessment of phytoplankton physiology, f , for improved estimates of primary productivity.
- A biophysical model, which accounts for algal physiological variability, can be utilized:
$$PP = ARP/Z_{685} \cdot \Phi_p'(\text{PAR}, f) \cdot \phi_e \cdot M_c$$


Alternative platforms: Geostationary satellites




View from Moon: 361979 km above 27° 14'S 82° 32'W




Φ_p' :



CFE:





Concluding Note:

Spring 2004: No AOL field measurements....

A.M. Chekalyuk^{1,3}, F.E. Hoge³,
R.N. Swift², J.K. Yungel², P.E. Lyon²

¹*Hampton University*, ²*EG&G Services*,

³*NASA Goddard Space Flight Center*

Wallops Flight Facility, *chekaluk@osb.wff.nasa.gov*