

# MODIS/Aqua Evaluations

---

**Chuck McClain**

**Gene Feldman**


**OCDP Staff**

**NASA/GSFC**

**NASA Ocean Color Research Team Meeting**

**April 14-16, 2004**


**Washington, DC**



# MODIS Processing Strategy

---

- Initial focus on MODIS/Aqua
  - MODIS/Aqua more stable than MODIS/Terra
  - MODIS/Aqua overlap with NPP/VIIRS
- Initial emphasis on calibration & Lwn's
  - Large seasonal/regional differences between MODIS/(Terra & Aqua) & SeaWiFS Lwn's
- Reduced product set until radiometry verified
  - Simplify processing for radiometry evaluations
  - Maintain a baseline consistent with SeaWiFS product suite. Expand product suite later.



# MODIS Ocean Color Parameters

- **Previous OC Parameter Set**


- Normalized water-leaving radiances (7)
- Aerosol optical thickness (865 nm)
- Atmospheric correction epsilon
- Aerosol model numbers (2)
- Clear water aerosol correction epsilon
- CZCS pigment concentration
- Chlorophyll-a concentration (3)
- Total pigment concentration
- Chlorophyll fluorescence line height
- Chlorophyll fluorescence baseline
- Chlorophyll fluorescence efficiency
- Total suspended matter
- Coccolithophore pigment concentration
- Detached coccolithophore concentration
- Calcite concentration
- Diffuse attenuation at 490 nm
- Phycoerythrobilin concentration
- Phycourobilin concentration
- Instantaneous PAR
- Instantaneous absorbed radiation for fluorescence
- Gelbstoff absorption coefficient at 400 nm
- Phytoplankton absorption coefficient at 675 nm
- Total absorption coefficients (5)
- Primary production (2 at Level-4)

- **Current OC Parameter Set**

- Normalized water-leaving radiances (6)
- Aerosol optical thickness
- Atmospheric correction epsilon
- Ångström exponent
- Chlorophyll-a (1)
- Diffuse attenuation coefficient at 490 nm

<b>Previous OC Parameter Set</b>	<b>38</b>
(does not include archived ancillary data & quality control fields)	


<b>Current OC Parameter Suite</b>	<b>11</b>
(does not include archived ancillary data)	




# Evaluation Approach

---

- Apply same cal/val approach as for SeaWiFS
- Use common processing codes
- Work sensor calibration issues with MCST
  - Solar and lunar calibration analysis and products, e.g., calibration tables, response-vs-scan (RVS), sensor polarization.
- Systematically test algorithms using both SeaWiFS & MODIS for comparison
  - Polarization, BRDF, glint, cloud masking, etc.
  - Global time series with regional analyses (clear-water, deep-water, coastal, basin-latitude zones)



# SeaWiFS Calibration Strategy




# MODIS/SeaWiFS Comparisons

---





- MODIS polarization correction
  - Original tables
  - No correction
  - Phase-shifted tables
  - Phase-shifted and approximately 2X-amplitude tables
- BRDF correction (based on Morel et al., 2002)
  - Fresnel-only (flat surface; no wind speed dependence)
  - Morel  $\mathcal{R}$  (wind speed dependent)
  - Morel  $\mathcal{R}$  and  $f/Q$
- Other
  - Sunlint radiance threshold
  - Cloud mask threshold

• MODIS polarization tables based on prelaunch characterization table.  
• SeaWiFS essentially polarization insensitive.




# Lwn: MODIS/SeaWiFS Ratios

## Deep-Water




# MODIS(Aqua)/SeaWiFS L<sub>w</sub>n Ratios (N. Pacific): Original polarization correction






# MODIS(Aqua)/SeaWiFS Lwn Ratios (N. Pacific): No polarization correction

MODIS(AT01)/SeaWiFS(ST01) 4-Day Water-Leaving Radiance Ratios, PacN50 Su



# MODIS(Aqua)/SeaWiFS Lwn Ratios (N. Pacific): Correct polarization (corrected phase & magnitude)




# SeaWiFS & MODIS 4-Day Deep-Water Chlorophyll Images

4 day composites, Summer 2002




0.01-1 mg/m<sup>3</sup>

SeaWiFS















MODIS  
(Correct polarization  
phase & amplitude)




# SeaWiFS Lw ODPS R4



# MODIS/Aqua Lw ODPS R1



## ODPS R4 OC4 Chlorophyll



## ODPS R1 OC3 Chlorophyll



# MODIS/Aqua Reprocessing Recommendations

---

- Use MCST temporally smoothed calibration tables
- Use phase & magnitude corrected polarization tables
  - Polarization working group to designate final table
    - Working group: Meister, Voss, Walushka, Xiong, Gordon
- Use “Fresnel-only” BRDF correction
  - Bio-optical algorithm working group needs to recommend standard algorithm for BRDF
- Use OC3 chlorophyll-a algorithm
  - Bio-optical algorithm working group needs to recommend standard chlorophyll algorithm for all sensors
- Keep current product set
  - Science team & HQ need to define updated product set



# Additional Sensor Calibration Issues

---

- Temporal stability: long-term and seasonal
- Refine “Response vs. Scan” (RVS) or scan modulation functions
- Minimize mirror-side calibration differences (image banding)
- Detector to detector calibration (striping)

Analyses to be conducted in collaboration with MCST and science community.

